

Sample Prep Instruments

a) Tyler Ro-Tap Sieve Shaker



a) US Standard Sieves

We have sieves. We have lots, and lots of sieves. We can do a quantitative sediment analysis on just about any size of sample you can send us. The best sort for texture & environment of deposition is 0Ø-1Ø-2Ø-3Ø-4Ø. Everything that sorts out to be smaller than 63µ gets put in the “clay size fraction” for a weight percent analysis.

Ask me about what kind of microelement analysis we can do using sieves.