


City & State of Downlink Location      Carlsbad NM  
 BLM Office                                      Carlsbad Field Office  
 Diagram Contact                                Mr. Doug  
 Diagram Code:                                  CarlsbadNM

Diagram: 02/10/04



Site Specific Instructions and Comments

For PTT Program:  
 Turn VCR ON, set manual switch to Channel 3 and Select Channel 03 on Remote.  
 Press TV./VCR Button on VCR to set to TV.  
 Press the "Who-Input Button" to select "VID" (this selects the RCA Inputs).  
 If Satellite Audio Button on AT2001 is ON Audio will be heard thru the TV and AT2001.  
 If Satellite Audio Button on AT2001 is OFF Audio will NOT be heard thru the TV or AT2001.  
 To dial in to PTT... Internal Speaker Button = ON, Satellite Audio Button = OFF, Manual Answer Button = ON  
 Listen to dial tone thru AT2001 and dial using the keys on the AT2001.  
 Once connected to the bridge, login using password.  
 Press the Satellite Audio Button ON listen to the broadcast thru the AT2001 and the TV.

End of PTT Program:  
 Press all Buttons on AT2001 to OFF setting.  
 Press the "Who-Input Button" to select TV/Channel 3 (this selects the Coax Input)

NOTE: Audio Out R on VCR to Audio In R of TV needs to be disconnected. Doug knows this, however he muted the TV last program and thinks that worked good.

Carlsbad Field Office  
 Carlsbad NM